

Mid Spreader/Foot Pads

BR-5S/FP-3

⚠ WARNING

Before operating this equipment, please read this manual carefully and retain this for future reference. Please read carefully and retain this instruction

This equipment may cause harmful, if not installed and used in accordance with this manual.

- Please read careful this manual before using.
- Please keep this manual for safety reason.

Attention to users

⚠ CAUTION This equipment may cause harm, if not installed and used in accordance with following instructions.

■ Safety Instruction.

When spread the BR-5S, carefully open in order to prevent from other obstacles.

■ Keep the maximum load capacity.

Keep the maximum load capacity. Excess load capacity may cause damage to equipments and unexpected incident.

■ Check if the tripod used for BR-5S/FP-3 is suitable.

If used inappropriately, which may cause unexpected incident or harmful to users.

■ Firmly tightened the extension lock knob and mid spreader joint before usage. Please confirm the lock.

If not properly locked which may cause unexecuted damage to camera or harmful to users.


■ Do not use for other purpose.

■ Do not dismantle or remold which cause breakdown of this equipment or harmful to users. In case of trouble, please ask service center.

Caution for users


Do not mount the camera on to the tripod without BR-5S/ FP-3.

Part name




How to attach the BR-5S to tripod

- 1 Insert the mid spreader joint into U ditch in the leg joint until click sounds.
- 2 After installed the mid spreader, please check carefully that mid spreader is firmly locked.



How to release the BR-5S

Hold the mid spreader release knob at one time, then pull it out. Easy to release the first leg by move of other legs to outward.



How to attach the foot pads FP-3

- 1 Set the leg spike on the FP-3 foot pad part.
- 2 Pull the rubber and place on to the spike.
- 3 Same way for other 2 legs.

