




No.	PART No.	DESCRIPTION	Q'TY USED	NOTE
1	THG3-1	1/4"&3/8" Screw adapter	1	
2	THG3-2	8pin expansion port cover	1	2 Pcs. set (with screws)
3	THG3-3	Arm lock screw	4	
4	THG3-4	Plate lock screw	1	
5	THG3-5	Pan arm cover	1	
6	THG3-6	Tilt arm cover	1	
7	THG3-7	Joy stick	1	
8	THG3-8	Foot rubber	1	3 Pcs. set

No.	PART No.	DESCRIPTION	Q'TY USED	NOTE
9	THG3-9	Mini tripod	1	
10	THG3-10	Li-ion battery for TH-G3	1	4 Pcs. set 
11	THG3-11	Li-ion battery charger for TH-G3	1	With charger cable 
12	THG3-12	Height adjusting plate	1	
13	THG3-13	Sliding plate	1	
14	THG3-14	1/4" Camera screw	1	
15	THG3-15	Lens support	1	With lock knob 
16	THG3-16	Carrying case	1	Without shoulder strap
17	THG3-17	Shoulder strap for carrying case	1	
18	THG3-18	PC connecting cable	1	For firmware updates
19	THG3-19	MINI-001 Cable	1	For Canon
20	THG3-20	MINI-002 Cable	1	For Canon
21	THG3-21	MULTI-001 Cable	1	For SONY
22	THG3-22	CTIA-001 Cable	1	For Panasonic
23	THG3-23	TypeC-001 Cable	1	Optional