




No.	PART No.	DESCRIPTION	QTY USED PER PROD	NOTE
1	THX2-1	Head assembly		
2	THX2-2	Sliding plate	1	
3	THX2-3	Sliding plate lock	1	
4	THX2-4	Tilt lock knob set	1	
5	THX2-5	Pan lock knob set	1	
6	THX2-6	Bubble level assembly	1	
7	THX2-7	Bowl clamp	1	
8	THX2-8	TH-X H Pan handle	1	
9	THX2-9	Pan handle assembly	1	
10	THX2-10	Pan handle holder assembly	1	
11	THX2-11	Pan handle lock	1	
12	THX2-12	Tripod bowl		
13	THX2-13	Leg assembly		
14	THX2-14	Leg lock knob	6	
15	THX2-15	Middle leg push-piece & plate	3	
16	THX2-16	Lower leg push-piece & plate	3	
17	THX2-17	Foot rubber × 3 pcs	1	
18	THX2-18	Mid-level spreader		
19	THX2-19	Transport lock	1	
20	THX2-20	Leg fixing plate × 3 pcs	1	
21	THX2-21	Carrying handle	1	
A	THX2-A	Camera platform assembly	1	
B	THX2-B	Ball leveler	1	

【Remarks】

⑮ and ⑯ have a specific installation direction, please assemble them referring to the illustration.