



No.	PART No.	DESCRIPTION	Q'TY USED	NOTE
A	DL10RB-A	Leg band	3	
B	DL10RB-B	Track lock knob (red)	1	
C	DL10RB-C	Track lock knob (grey)	2	
D	DL10RB-D	Cable guard	3	
E	DL10RB-E	Cable guard lock knob	3	
F	DL10RB-F	Pedestal column lock screw	1	
G	DL10RB-G	Pedestal column pressure plate	1	
1	DL10RB-1	Dolly base	1	
2	DL10RB-2	Dolly leg assembly (A)	1	
3	DL10RB-3	Dolly leg assembly (B)	2	
4	DL10RB-4	Dolly center leg cap	2	
5	DL10RB-5	Dolly shaft	2	
6	DL10RB-6	Lock pin	2	
7	DL10RB-7	Dolly outside leg cap	3	with Parts
8	DL10RB-8	Track lock base	3	
9	DL10RB-9	Caster (Double-wheel caster)	3	
10	DL10RB-10	Cable guard stay	3	